

# Overhead door closer RYOBI D-3200 SERIES

# D-3200 SERIES


### **Model chart**

Size	Without hold-open			Maximum door	Maximum door
		Without backcheck	Delayed action	weight	width
Size3-6	Standard application	D-3200	D-3200DA	60-120kg	950-1400mm
Size3-5	Top jamb application			60-100kg	950-1250mm
Size1-4	Track-rail arm application	D-3200T	D-3200DAT	20-80kg	750-1100mm
Size3-5	Parallel arm application	D-3200P	D-3200DAP	60-100kg	950-1250mm


<sup>\*:</sup> D-3200 univ is a set to handle both standard application and parallel arm application.

Slim-line body and smooth operation
CE EN1154 (inc. CE EN1634 part.1)
Standard backcheck and optional delayed action functions
Support of door sizes 3 through 6 by closing power adjustment
Non-handed
Wide color variation


D-3200 Standard application



D-3200T Track-rail arm application



D-3200P Parallel arm application




### **Color variation**




# **Specification and adjustment**

#### Two speed control valves


- •There are two speed ranges for door closing speed.
- •Those ranges are classified into two stages of the 1st speed range which controls overall door closing speed and the 2nd speed range which controls latching speed.
- •Those speeds can be adjusted by respectively independent speed adjustment valves.






#### **Backcheck function**

- •This function controls sudden door opening by strong wind, etc.
- •This function prevents accidents, injuries, and door damage which occur due to a door suddenly opening by a strong wind or rough handling.
- •This function works in a range of door opening angles from approx. 80 to 180 degrees.
- •The door becomes heavier when it operates, however, this is all by design. The door opens if it is slowly opened.
- •When installing the door closer equipped with the backcheck function, sufficiently reinforce hinges and pivots.



## **Delayed action**

- •This function allows additional closing time from a full open angle to approx. 70 degrees.
- Delayed time can be adjusted to vary from seconds to minutes by the delayed action adjustment valve.
- Delayed closing action is an advantage to Nursing staff assisting patients, Domestic staff pushing meals or maintenance trolleys, and the elderly or infirm walking with sticks or frames under supervision.




Backcheck operating range

# Closing power adjustment

- •Spring power adjustable according to door weight and width,
- Factory preset size 3 standard installation.






# D-3200 Standard application

# D-3200/D-3200DA






# D-3200 Top jamb application

### D-3200/D-3200DA






# D-3200 Track-rail arm application

# D-3200T/D-3200DAT





# **D-3200 Parallel arm application**

### D-3200P/D-3200DAP



